



Note: Prestressed Concrete Panels may be used only when the Construction Joint is at Centerline of Beam. See Bridge Design Manual for more information about Staged Construction.

Fig. 5-15